



P/N	Connector Figure	Radio Brand	Radio Models
K1		RELM	RPV516A, 599A, Plus/RPU416A, 499A Plus
		Kenwood	TK-208, TK-2100(ProTalk), TK-2102(ProPower), TK-2130(ProTalk XLS), TK-220, TK-240, TK-240D, TK-248, TK-250, TK-260, TK-260G, TK-270, TK-270G, TK-308, TK-3100(ProTalk), TK-3101(FreeTalk XL), TK-3102(ProPower), TK-3130(ProTalk XLS), TK-3131 (FreeTalk XLS), TK-320, TK-340, TK-340D, TK-348, TK-350, TK-353, TK-360, TK-360G, TK-370, TK-370G, TK-372G, TK-430, TK-431, TK2200, TK2202, TK3202, TK3200, TK3201, TK2160, TK3160, TK2170, TK3170, TK208, TK373, TK3173
M2		Motorola	Visar Series
M1		Motorola	CP100, CP125, CP150, CP200, CT150, CT250, CT450, CT450LS, GP2000, GP350, GP300, GP308, GP280, GP68, GP88, GTI, GTX, LTS2000, P040, P080, P110, P1225, P1225LS, PR400, PRO3150, SP10, SP21, SP50, XTN446, XTN500, XTN600, XV1100, XV2100, XU1100, XU2100, XU2600, VL130, VL50, BPR40, DTR Series
		Blackbox	Blackbox-V, Blackbox-U
S6		Icom	F11, F21, F14, F14S, F24, F24S, F33G, F43G, F43TR, F3021, F4021
Y4		Vertex	VX130, VX160, VX180, VX210, VX210A, VX350, VX400, VX410, VX420
F		Sprint/Nextel	Falcon Series; i205, i265, i275, i305, i315, i325, i335, i355, i530, i560, i570, i580, i605, i670, i730, i733, i736, i710, i760, i830, i836, i850, i860, i870, i880, i930, ic402, ic502, ic602, ic902